



Cowl Stabilizers

Installation of the cowl stabilizers requires removal of the fenders. Fender removal varies between years. We recommend following factory service manuals for removal.

A small section of the seam needs to be removed or bent before installing the braces.



Before removing door hinge bolts, trace the outline of the door hinges. Using masking tape on the door seems to help hold the doors in place.

Remove the two lower hinge bolts and the lower upper hinge bolt, then set the brace into place. The original OE hardware or the new supplied hardware can be used to attach the braces to the hinge area. **Start all fasteners before tightening any one the bolts.** Once the braces are in place and all fasteners have been tightened, two 8mm or 5/16" holes will need to

be drilled using the holes in the boxes as guides. **Make sure the area of the engine bay is clear of wires and other items before drilling.** Fasten the brace through the new holes to the supplied backing plate. Re install fenders.

Please feel free to contact us with any questions. Reviews and feedback are always appreciated.

www.V8Roadsters.com

sales@v8roadsters.com

813-532-2786