



Billet Rear Hubs

Miata hubs are shipped with a light coating of oil to prevent surface rust after machining. Remove the oil before pressing the hub into the wheel bearing using WD40 and a cloth.

We recommend professional installation of the hubs into the upright bearing. Hubs must be pressed square into the bearing or damage to the hub or bearing may occur. Make sure the hub and bearing surface are clean of all debris before pressing in. Clean splines of axle before reinstalling into the hub and add a small amount of anti-seize to the clean splines.

Axle nuts should be torqued to 225ft-lbs. Nut torque should be checked after the first outing, and then again after 100 miles or two track sessions.

Please feel free to contact us with any questions. Reviews and feedback are always appreciated.

www.V8Roadsters.com

sales@v8roadsters.com

813-532-2786

